



Wall: Solid construction *Windtight and rainproof on the outside*

Joining roof underlay membrane to solid wall construction - plastered masonry



Example of a dormer wall connection:

Example of a chimney:

- Clean the substrate and roof underlay membrane
- Apply Primur, align it and press on firmly
- Make a stress-relief loop in the membrane, press down the membrane firmly without tension or wrinkles
- Cut off any excess membrane




Primur® roll

P. 115

Wall: Solid construction

Windtight and rainproof on the outside



Alternatively:



Example of a chimney:

- Bond the membrane with Docks skin and Wigluv 100 or Wigluv 150 to the masonry or plaster



Wigluv® 100 & 150

P. 122

Docks skin®

P. 119