



Purlin joint



- Bond Corvum accurately to the purlin below the rafters with the pre-folded edge at the top
- Press on firmly



- Successively remove backing strip and bond vapour control layer to smooth inner of Corvum
- Press on firmly



- Unfold Corvum and mount vapour control layer

How it should look:

- The purlins have been airtightly bonded with Corvum 30/30



Corvum® 30/30

P. 116