Windtight and rainproof on the outside



Roof

Roof underlay membrane penetration



- Guide the membrane precisely around the circular penetration
- Note: Start sealing at the lowest point!
 Provides extra protection against water penetration



- Fix Wigluv half on the circular penetration, then half on the membrane
- Press down firmly
- Apply subsequent pieces in overlapping layers



How it should look:

- Circular penetration sealed windtightly in layers with Wigluv 60
- Water will reliably run off



Wigluv[®]60

P 120

siga.swiss 99