



## Wall: Timber construction

### *Windtight and rainproof on the outside*

#### Facade membrane penetration



- Cut off Wigluv 20/40: leave approx. 4 cm on both sides
- Separate the narrow backing strip and affix in the corner
- Separate the wide backing strip and press on firmly
- Cut the corner at 45°



- Fold over
- Press on



- Repeat at each side of the penetration

## Wall: Timber construction Windtight and rainproof on the outside



### How it should look:

- Square penetration sealed windtight using Wigluv 20/40.

### How it should look:

- Penetration of open facade sealed windtight using Wigluv black

### For closed facades:



**Wigluv® 20/40**

### For open facades:



**Wigluv® black 20/40**



## Wall: Timber construction

### *Windtight and rainproof on the outside*

#### Joining window to facade membrane



- Pre-fold the corner using Wigluv 20/40
- Affix precisely in the window corner
- Repeat at all corners



#### Connect corners:

- Align Wigluv 20/40 in the corner
- Remove narrow backing strip
- Affix the narrow side to the window frame and press on




- Remove the wide backing strip
- Affix the wide side to the facade membrane and press on firmly

## Wall: Timber construction Windtight and rainproof on the outside



### How it should look:

- Window sealed windtight using Wigluv 20/40



### How it should look:

- The window next to a visible facade is sealed windtight with Wigluv black

### For closed facades:



### For open facades:



**Wigluv® 20/40**

**Wigluv® black 20/40**