



Roof *Airtight on the inside*

Mounting vapour control layer under flat or inclined roofs



- Use double-sided adhesive Twinet when mounting vapour control layers on timber or metal substructures
- Avoids leaky stapling points



- Apply vapour control layer with the writing facing you




- Seal overlap with Sicrall avoiding tension and wrinkles



How it should look:


- Vapour control layer mounted on rafters/substructure and bonded to be permanently airtight



After sealing



- Attach battens across structure to bear the weight of the insulation material
- Mount the interior cladding (protects against mechanical influences and UV radiation)
- For wide joists or extremely high insulation material weight we recommend installation of the membrane in the direction of the rafters, sealing in the rafter area and longitudinal installation of the battens



Majrex®

P. 108

Majpell 5

P. 109

Twinet®

P. 118